




MODEL UVA 5000

UV Absorbance Process Photometer



Features

- Compact, space-saving configuration with no moving parts that is available for use in either hazardous or non-hazardous rated areas
- 316SS High-Pressure rated Sample Cell that is isolated from the analyzer electronics
- Optical design approach that compensates for source and detector aging
- Long-Life, Pulsed UV Xenon Flash Lamp
- Photomultiplier Tube (PMT) detector which provides a highly sensitive and stable measurement of the gas of interest
- Touch-Screen User Interface with intuitive mode buttons & menus that also provides visual diagnostic information by an automatic change in concentration display color

Description

The CAI Model UVA-5000 utilizes the field-proven UV Absorbance method to continuously detect gas-phase compounds that are capable of absorbing UV light energy. It utilizes Beer's Law, the attenuation of light as it passes through a flowing sample gas, to monitor for changes in concentration of the desired analyte. The CAI UVA 5000 consists of a pulsed, UV Xenon lamp, 2 x fiber optic cables, a flow-through, temperature-controlled sample cell and a PMT (Measure) & PbSe photodiode (Reference) detector. Light energy from the pulsed Xenon lamp is fed via a fiber optic cable to a cross-flow sample cell. The light passing through the flowing sample is collected by the receiving fiber and conveyed to the photo-multiplier tube (PMT) measurement detector to provide a continuous analysis of the compound of interest. A beam splitter is employed to direct the attenuated light to both the measurement and reference detectors. CAI selects and incorporates specific measure & reference wavelength optical filters into the light path based upon the given application.



Gas Phase Sample Flow Cell fitted with Optical Fiber Couplers

Typical Applications

- Trace H₂S in Natural Gas / Amine Scrubbers
- Trace SO₂ in Flue Gas Desulfurization (FGD)
- Trace CL₂ in Stack Gas & Process Scrubbers
- Trace CLO₂ Analysis in the Pulp & Paper Ind.
- % F₂ in UF₆ Analysis / Nuclear Fuel Processing


MODEL UVA 5000

UV Absorbance Process Photometer

Specifications

- Measurement Principle** – UV Absorbance
- Light Source** – Pulsed UV Xenon Flash Lamp
- Detector** – Photomultiplier Tube (PMT) Detector
- Fiber Optic Cables** – (2) x 1 meter, 600 micron core cables
- Sample Flow Cell** – 316 Stainless Steel Cross Flow Cell (*)
- Range** – Application Dependent- Contact Factory
- Response Time** – Electronic Response is T90 in 2 seconds
- Accuracy** – Typically +/-1% of F.S. - (Appl Dependent)
- Power Requirement** – 24VDC Nominal (12 to 48VDC), 8.5 Watts
- Enclosure** – NEMA4X or EXD Configurations Available
- Process Temperature** – 200 Deg C (max)
- Process Pressure** – Up to 2,000 psig (max)
- Minimum Flow Rate** – 100 ml/min
- Operating Temperature** – 0 to 50 Deg C
- Storage Temperature** – 0 to 50 Deg C
- Outputs** – 4-20mA, RS485 (MODBUS) or USB
- Alarms** – Contact Closure (60VDC, 0.75A Max)
- Display** – 3.2" Capacitive Touch Screen LCD

(*) = CAI can provide the sample cell in other exotic alloys for corrosive sample conditions.



Specifications subject to change without notice.



California Analytical Instruments

1312 West Grove Ave., Orange, CA 92865

Phone: 714-974-5560 • Fax: 714-921-2531

www.gasanalyzers.com